



JDMuscle – 3M Tape Installation Guide

This guide is designed to help you achieve a clean, secure, and professional installation of car parts using 3M automotive double-sided tape. Parts include spoilers, window visors, trim pieces, and more.

Tools & Supplies Needed

- Isopropyl alcohol (70% or higher)
- Clean microfiber cloth
- Masking tape (optional, for alignment)
- Heat gun or hair dryer (optional, for improved adhesion)

Installation Steps

1. Test Fit the Part

- Position the part on the vehicle to confirm alignment and fit.
- Use masking tape to mark reference points if needed.

2. Clean the Surface

- Thoroughly clean the installation area using isopropyl alcohol and a microfiber cloth.
- Ensure the surface is free of dust, oil, wax, and debris.
- Allow it to dry completely.

3. Warm the Tape (Optional but Recommended)

- If the temperature is below 70°F (21°C), gently warm the 3M tape and surface with a heat gun or hair dryer.
- Warming helps activate the adhesive and improves bonding.

4. Peel and Position

- Peel back a small portion of the red backing tape on each end of the part (do not remove it entirely yet).

- Align the part with your reference marks.
- Lightly press it in place.

5. Final Tape Removal and Installation

- While holding the part in place, slowly pull off the remaining backing tape.
- Press the part down firmly as you go.
- Apply even pressure across the entire surface to ensure proper contact.

6. Secure and Let Cure

- Apply firm pressure for at least 30 seconds across the part.
- Do not wash the vehicle or expose it to water for 24 hours.
- Full adhesive cure is typically reached in 72 hours.

Tips for Best Results

- Install indoors or in the shade.
- Avoid installing in very cold, wet, or humid conditions.
- Don't stretch or force the part during installation.

Need Help?

JDMuscle USA Support

- **Phone:** (866) 833-3536
- **Email:** sales@jdmuscleusa.com
- **Website:** www.jdmuscleusa.com
- **Hours:** Mon–Fri, 9:00 AM – 5:00 PM EST

Show Off Your Install!

- Tag us on Instagram @JDMuscleUSA to get featured!

Final Notes

Always follow specific product instructions when available. These are general installation steps suitable for most exterior automotive parts using 3M tape.